LOCKNLOCK HOT & COOL USER MANUAL

HOW TO USE

- Before first use rinse the lid, strainer and the interior of the bottle thoroughly with warm water. Be sure that silicone seal rubbers are correctly attached.
- For better heat retention, preheat or precool the bottle before filling.
- Wash the bottle thoroughly with warm water after each use.
- Keep in cool, well-ventilated area.

WARNING & CAUTION

- This product is for keeping beverages hot or cool.
 Do not use for other purposes.
- Do not exceed the fill level as of 1 centimetre below the cap.
- Keep out of the reach of children when containing hot liquids.
- Be careful not to scald yourself when the product contains hot drinks.
 (Due to the high level of thermal efficiency, the exterior of the vacuum product will not be hot)
- Do not put the bottle on or near heat sources/naked flames.
- Do not use in microwave.
- Do not use in refrigerator.
- Do not fill with dry ice, carbonated drinks, dairy products and liquids or soups containing salt.
- Keep the bottle in an upright position to avoid spillages.

CLEANING

- Wash the bottle thoroughly with warm water after each use.
- Remove the rubber seal from the lid before washing.
- Do not use in a dishwasher/dryer.
- Do not boil to sanitize.
- Do not use bleaches or other harsh/abrasive cleaners.
- To sterilize put hot water mixed with 1 spoon of baking soda into the bottle and leave it uncovered. Rinse with warm water after 30 minutes.

Tip: To remove rust spots and water stains, fill product with hot water and 10% vinegar and leave for 30 minutes. Rinse and wash thoroughly.